


















▶ TETRA Radio Connectors ◀

ORIGINAL MANUFACTURER	ORDER CODE	RADIO MODELS
MOTOROLA	M7 	MTH650, MTH800, MTP850 with locking screw
MOTOROLA	M8 	MTP850
MOTOROLA	M9 	MTH650, MTH800
MOTOROLA	M10 	MTP700
EADS/NOKIA	E1 	THR880/i with built in DC charger socket.
EADS/NOKIA	E2 	THR880/i with built in DC charger socket.
EADS/NOKIA	E3 	THR9
EADS/NOKIA	E4 	TETRAPOL G2 (MC9620)
SEPURA	S1 	SRP2000, SRH 3000 Series

ORIGINAL MANUFACTURER	ORDER CODE	RADIO MODELS
SEPURA	S2 	SRP2000, SRH 3000 Series
SEPURA	S3 	STP8000
KENWOOD/RELM	K1 	TK2102 (Power Pro), TK2130 (Pro Talk XLS), TK3130 (Pro Talk XLS), TK220, TK240, TK248, TK250, TK260, TK260G, TK270, TK270G, TK308, TK2100 (Pro Talk), TK2200 (Pro Talk), TK3100 (Pro Talk), TK3200 (Pro Talk), TK3201 (Pro Talk), TK3202 (Pro Power), TK3131 (Free Talk XLS), TK320, TK340, TK340D, TK348, TK350, TK353, TK360, TK360G, TK370, TK370G, TK372, TK3101 (Free Talk XL), TK372G, TK373, TK430, TK431, TK2160, TK3160
KENWOOD	K2 	TK2140, TK3140, TK3180, TK280, TK380, TK480, TK481, TK190, TK290, TK390, TK2180, TK3180, TK3212, TK2212, TK5210, TK190, TK5400, NEXEDGE, NX200/300
MOTOROLA	M1 	CP88, CP100, CP150, CP200, CT150, CT250, CT450, CT450LS, GP2000, GP300, GP308, GP68, GP88, BC120, GTI, GTX, LTS2000, PR400, P040, P080, P110, P11215, P1225LS, PRO3150, SP10, SP21, SP50, XTN446, XTN500, XTN600, XV1100, XV2100, XU1100, XU2100, XU2600, VL130, VL50, MAG ONE/BPR40
MOTOROLA	M2 	GP1280, GP140, GP320, GP328, GP329, GP338, GP339, GP340, GP360, GP380, GP640, GP650, GP680, HT1250, HT1250LS, HT1550, HT1550XLS, HT750, MTX8250, MTX8250LS, MTX850, MTX850LS, MTX9250, MTX950, PRO5150, PRO5350, PRO5450, PRO5550, PRO5750, PRO7150, PRO7350, PRO7450, PRO7550, PRO9150, PTX700, PTX760, PTX780
MOTOROLA/RELM	M3 	MOTOROLA: EX500, EX600, GL2000, GP328PLUS, GP344, GP388, PRO5150 ELITE MULTIPIN with LOCKING SCREW RELM:RPV3000, RPV3600, RPU3000, RPU3600
MOTOROLA/EF JOHNSON	M4 	MOTOROLA: GP900, GP9000, HT1000, JT1000, MT2000, MTS2000, MTX8000, MTX838, MTX838, MTX900, MTX9000, MTX960, MTX-LS, XTS2500, XTS3000ASTRO, XTS3500, XTS5000, XTS3000 EF JOHNSON: 51SL, 5000 SERIES, 5100 SERIES, 7700 SERIES
MOTOROLA	M5 	3.5mm straight stereo, VISAR Series

ORIGINAL MANUFACTURER	ORDER CODE	RADIO MODELS
MOTOROLA	M6 	MOTOROLA TBRO
HRS	HR6 	Hirose 6 pin
MACOM	MC1 	Jaguar 700P, P7100, P7130, P7150, P7170, P5100, P5130, P5150
MACOM	MC2 	LPE 200 PRISM
SIMOCO	SIM1 	SIMOCO SRP SERIES
HYT	HY1 	HYT TC500, HYT 2100, TC500, TC600, TC610, TC620, TC700, TC1600, TC2100
ICOM/MAXON/RITRON/VERTEX	I1 	ICOM: F3, F3S, F4, F4S, F4TR, F10, F20, H2, H6, J12, M5, U12, U16, 4008, 4088A, ALL ICOM DUAL PIN AMATEUR RADIOS MAXON: SL25, SL55, SP100, SP120, SP130, SP140 RITRON: PATRIOT SERIES RTX, SST, JOBCOM SMX, MBX VERTEX: VX200, VX500, VX510, VX520UD
ICOM	I3 	ICOM F30G, F30GT, F30GS, F31G, F31GS, F31GT, F40G, F40GS, F40GT, F41G, F50, F51F60, F70, F80, M87/88
ICOM	I2 	F3G, F3GS, F4G, F4GS, F11, F11S, F14, F14S, F15, F21, F21S, F22, F24, F24S, F31, F33, F43

ORIGINAL MANUFACTURER	ORDER CODE	RADIO MODELS
ICOM	I4 	ICOM F11 WITH LOCKING SCREW, F21, F14, F14S, F24, F24S, F33G, F43G, F43TR
VERTEX	VY1 	VX-820, VX920, VX821, VX921
VERTEX	VY2 	VX130, VX160, VX180, VX210, VX210A, VX400, VX410, VX420 with locking screws
VERTEX	VY3 	VX130, VX160, VX180, VX210, VX210A, VX400, VX410, VX420 with locking screws
VERTEX	VY4 	MH-360M, MH-450M, MH-50A7A, VH-110, VH115M, VH-120, VH-130, VH-215M, VH-225M, VX600, VX800, VX900, VX530
MAXON	MN1 	SL100 LEGACY
MAXON	MN2 	SL55
NEXUS	NX1 	NEXUS 4 PIN